



ATC 2008

MSP430 Advanced Technical Conference

Implementing an MSP430 Accelerometer-Based Data Acquisition System

Andreas Dannenberg

5/21/2008

1



Agenda



- Accelerometer Basics
- Interfacing to the MSP430
- Lab: Accelerometer and MSP430 Setup
- Lab: Low-Power Anti-Theft Alarm
- Lab: Tilt Ball


ATC 2008

MSP430 Advanced Technical Conference

2



MSP-EXP430F5438 Accelerometer Overview



- Two- or three-axis analog-output accelerometer are used
- Measures dynamic and static acceleration

ATC 2008

MSP430 Advanced Technical Conference

3



MSP-EXP430F5438 Accelerometer Specs

	ADXL322	ADXL330
Number of Axis	2 (X, Y)	3 (X, Y, Z)
Sensitivity	420mV/g	300mV/g
Measurement Range	±2g	±3.6g
Current Consumption	450μA	320μA
Wakeup Time	20ms	1ms

Which one is used on your board?


ATC 2008

MSP430 Advanced Technical Conference

4



Output Response vs. Orientation




ATC 2008

MSP430 Advanced Technical Conference

5



Accelerometer Output Voltage Distribution



Zero-g Output Performance @ $V_{CC} = 3V$

ATC 2008

MSP430 Advanced Technical Conference

6



Agenda



- Accelerometer Basics
- Interfacing to the MSP430
- Lab: Accelerometer and MSP430 Setup
- Lab: Low-Power Anti-Theft Alarm
- Lab: Tilt Ball


ATC 2008

MSP430 Advanced Technical Conference

7



MSP430F5438 – Accelerometer Connections



- Accelerometer is powered by the MSP430 – allowing on-demand operation

ATC 2008


MSP430 Advanced Technical Conference

8



MSP430F5438 ADC12 Enhanced Features

- Low power modes
 - Selectable speed vs. power mode
 - References automatically shut down to conserve power
- High clock dividers for fast system clocks
- Low I_{CC}
 - 130 μ A for ADC
 - 100 μ A for V_{REF}



ATC 2008



MSP430 Advanced Technical Conference

9



MSP430F5438 GPIO Features

- Programmable Reduced/Full drive strengths (PxDS)
- Internal programmable pull-up/down pin resistors on every port pin




ATC 2008

MSP430 Advanced Technical Conference

10



Accelerometer Turn-On Behavior (PxDS = 0)



ATC 2008

MSP430 Advanced Technical Conference

11



Agenda



- Accelerometer Basics
- Interfacing to the MSP430
- Lab: Accelerometer and MSP430 Setup
- Lab: Low-Power Anti-Theft Alarm
- Lab: Tilt Ball

ATC 2008

MSP430 Advanced Technical Conference

12



Lab 1: Goal

- Configure and use the MSP430 to periodically read out accelerometer sensor data using Timer_A and ADC12
- Calculate the physical g-force values from the ADC12 conversion results
- Display the X and Y g-force readings on the LCD in real-time every 100ms

ATC 2008

MSP430 Advanced Technical Conference

13



Before we get started...let's setup CCE!

- Open the TI CCE IDE
- Select "Import..." from the "File" menu
- Select "General/Existing Projects into Workspace"
- Select "Browse..." and navigate to the folder containing the lab / demo project folders
- The dialog box should now list three lab projects
- Select "Copy projects into workspace"
- Click on "Finish"

ATC 2008

MSP430 Advanced Technical Conference

14



Lab 1: Port-Pin Configuration

```
// Power the accelerometer through P6.x
P6OUT _____;
P6DIR _____;

// Configure P6.x, P6.x, and P6.x as analog pins
P6SEL _____;

// Configure P6.x, P6.x, and P6.x as inputs
P6DIR _____;
```

- Check the interconnections in the schematic
- Power the accelerometer through a port pin
- Configure analog pins for peripheral function
- **Note: Configure pins for 3-channel accelerometer**

ATC 2008

MSP430 Advanced Technical Conference

15



Lab 1: Timer_B Setup

```
// Use TBCLK = ACLK, clear TBR
TBCTL = _____;
// Set OUT1 on EQU1, reset on EQU0
TBCCTL1 = _____;
// Set period to 1/10Hz
TBCCR0 = _____;
// Set EQU1 event
TBCCR1 = _____;
```

- Use TBCLK = ACLK = LFXT1 = 32,768kHz
- Use capture/compare block TB1 in compare mode
- Generate a rising edge on Timer_B.OUT1 every 100ms (will be used to trigger A/D conversions)

ATC 2008

MSP430 Advanced Technical Conference

16



Lab 1: ADC12 Setup 1/2

```
// Configure S&H time, enable multiple conversions,  
// enable ADC12  
ADC12CTL0 = _____;  
// Use Timer_B.OUT1 to trigger conversions,  
// pulse mode, single sequence of channels  
ADC12CTL1 = _____;  
// 12-bit mode, use signed output format  
ADC12CTL2 = _____;
```

- Configure the sample and hold time
- Use Timer_B.OUT1 to trigger the ADC12 start-of-conversion
- Use 12-bit mode
- Configure for signed output format

ATC 2008

MSP430 Advanced Technical Conference

17



Lab 1: ADC12 Setup 2/2

```
// Setup a two-channel ADC12 conversion sequence  
// Accelerometer X-channel  
ADC12MCTL0 = _____;  
// Accelerometer Y-channel, end-of-sequence  
ADC12MCTL1 = _____;  
// Enable interrupts on ADC12MEM1  
ADC12IE = _____;  
// Enable conversions  
ADC12CTL0 |= _____;
```

- Setup and convert a sequence of two channels (X and Y)
- Use A_{VCC} and A_{VSS} as reference
- Enable interrupts on ADC12MEM1
- Enable conversions

ATC 2008

MSP430 Advanced Technical Conference

18



Lab 1: ADC12 Interrupt Service Function

```
#pragma vector = ADC12_VECTOR
__interrupt void ADC12_ISR(void)
{
    ADCResultX = _____;    // Read out results, clear IFGs
    ADCResultY = _____;

    ADC12CTL0 _____;      // Toggle ADC12ENC
    ADC12CTL0 _____;

    __bic_SR_register_on_exit(LPM0_bits);
}
```

- Move conversion results to global variables
- Toggle the enable conversion bit to allow new SOC

ATC 2008

MSP430 Advanced Technical Conference

19



Lab 1: Calculating the g-Force Values

```
// Calculate the g-force values assuming a VCC of 3V
// to use the accelerometer's datasheet sensitivity factor.
// Since the output is ratiometric the actual VCC level
// doesn't matter.
```

```
AccelX = _____ ADCResultX _____;
AccelY = _____ ADCResultY _____;
```

- Check the User's Guide for details on how to interpret the ADC12 conversion data, and calculate the g-force values
- Start the code, and move the board around watching the g-force readings on the LCD.
- LED1 should toggle every 1s during operation

ATC 2008

MSP430 Advanced Technical Conference

20



Lab 1: Port-Pin Configuration – Solution

```
// Power the accelerometer through P6.0
P6OUT |= 0x01;
P6DIR |= 0x01;

// Configure P6.1, P6.2, and P6.3 as analog pins
P6SEL |= 0x0e;

// Configure P6.1, P6.2, and P6.3 as inputs
P6DIR &= ~0x0e;
```

ATC 2008

MSP430 Advanced Technical Conference

21



Lab 1: Timer_B Setup – Solution

```
// Use TBCLK = ACLK, clear TBR
TBCTL = TBSSEL_1 + TBCLR;
// Set OUT1 on EQU1, reset on EQU0
TBCCTL1 = OUTMOD_3;
// Set period to 1/10Hz
TBCCR0 = 32768 / 10;
// Set EQU1 event
TBCCR1 = TBCCR0 >> 1;
```

- Note that the value used for TBCCR1 is somewhat arbitrary however one needs to make sure it is within the count range of TBR

ATC 2008

MSP430 Advanced Technical Conference

22



Lab 1: ADC12 Setup 1/2 – Solution

```
// Configure S&H time, enable multiple conversions,  
// enable ADC12  
ADC12CTL0 = ADC12SHT0_6 + ADC12MSC + ADC12ON;  
// Use Timer_B.OUT1 to trigger conversions,  
// pulse mode, single sequence of channels  
ADC12CTL1 = ADC12SHS_3 + ADC12SHP + ADC12CONSEQ_1;  
// 12-bit mode, use signed output format  
ADC12CTL2 = ADC12RES_2 + ADC12DF;
```

ATC 2008

MSP430 Advanced Technical Conference

23



Lab 1: ADC12 Setup 2/2 – Solution

```
// Setup a two-channel ADC12 conversion sequence  
// Accelerometer X-channel  
ADC12MCTL0 = ADC12INCH_1;  
// Accelerometer Y-channel, end-of-sequence  
ADC12MCTL1 = ADC12INCH_2 + ADC12EOS;  
// Enable interrupts on ADC12MEM1  
ADC12IE = 0x0002;  
// Enable conversions  
ADC12CTL0 |= ADC12ENC;
```

ATC 2008

MSP430 Advanced Technical Conference

24



Lab 1: ADC12 ISR – Solution

```
#pragma vector = ADC12_VECTOR
__interrupt void ADC12_ISR(void)
{
    ADCResultX = ADC12MEM0;    // Read out results, clear IFGs
    ADCResultY = ADC12MEM1;

    ADC12CTL0 &= ~ADC12ENC;    // Toggle ADC12ENC
    ADC12CTL0 |= ADC12ENC;

    __bic_SR_register_on_exit(LPM0_bits);
}
```

- Toggling of ADC12ENC is needed to ready the ADC12 for the next sequence of channels to be converted when the next trigger occurs

ATC 2008

MSP430 Advanced Technical Conference

25



Lab 1: Calculating the g-Force Values – Solution

```
// Solution for ADXL322 (2-axis Accelerometer)
AccelX = 3.0f / 4096 / 0.42f * (ADCResultX >> 4);
AccelY = 3.0f / 4096 / 0.42f * (ADCResultY >> 4);
```

```
// Solution for ADXL330 (3-axis Accelerometer)
AccelX = 3.0f / 4096 / 0.30f * (ADCResultX >> 4);
AccelY = 3.0f / 4096 / 0.30f * (ADCResultY >> 4);
```

- Note that both flavors of accelerometers have a slightly different gain

ATC 2008

MSP430 Advanced Technical Conference

26



Agenda



- Accelerometer Basics
- Interfacing to the MSP430
- Lab: Accelerometer and MSP430 Setup
- Lab: Low-Power Anti-Theft Alarm
- Lab: Tilt Ball

ATC 2008

MSP430 Advanced Technical Conference

27



Lab 2: Goal

- Flash the LCD backlight and output a tone in case your MSP-EXP430F5438 gets moved
- Use low-power best practices to achieve lowest possible average current
 - Timer and interrupt-driven activity
 - On-demand accelerometer operation
 - Maximize time in low-power mode

ATC 2008

MSP430 Advanced Technical Conference

28



Lab 2: Timer_B Setup

```
// Use TBCLK = ACLK, clear TBR, enable TBR
// overflow interrupt
TBCTL = _____;
// Set 1s interval for overflow
TBCCR0 = _____;
// Set OUT1 on EQU1, reset on EQU0
TBCCTL1 = _____;
// Set EQU1 event. Used as accelerometer power-on delay and
// ADC12 start of conversion trigger via OUT1.
TBCCR1 = _____;
```

- Use TBCLK = ACLK = LFXT1 = 32,768kHz
- Setup for 1s overflow interval, enable interrupt
- Use TBCCR1 to trigger start of conversion, and to wait for the accelerometer to settle. How long is good?

ATC 2008

MSP430 Advanced Technical Conference

29



Lab 2: Accelerometer On-Demand Operation

```
void System_Init(void)
{
    // Init P6.x output latch to prepare powering
    // the accelerometer via ACC_PWR
    P6OUT _____;

#pragma vector = TIMERB1_VECTOR
__interrupt void TIMERB1_ISR(void)
{
    switch (__even_in_range(TBIV, 0x0e))
    {
        case 0x0e:                // TBIFG
            P6DIR _____;      // Set ACC_PWR to output to
                                   // power-up accelerometer
    }
}
```

- Idea: Switch accelerometer power signal between “output high” and “input” to achieve on-demand operation

ATC 2008

MSP430 Advanced Technical Conference

30



Lab 2: Low-Power Mode Handling 1/2

```
void main(void)
{
    (...)
    while (1)
    {
        // Wait in low-power mode X, enable interrupts
        __bis_SR_register(____);
    }
}
```

- Which low-power mode is most suitable and will result in the lowest possible stand-by current?
- The interrupts section in the User's Guide has more info
- Enter selected low-power mode to wait until an ADC12 conversion has been completed

ATC 2008

MSP430 Advanced Technical Conference

31



Lab 2: Low-Power Mode Handling 2/2

```
#pragma vector = ADC12_VECTOR
__interrupt void ADC12_ISR(void)
{
    (...)
    // Exit low-power mode
    __bic_SR_register_on_exit(____);
}
```

- Exit the low-power mode upon completion of the ADC12 ISR
- Clearing the low-power mode bits on the top of the stack will wake up the system's main() context – same as on all MSP430

ATC 2008

MSP430 Advanced Technical Conference

32



Lab 2: Finishing Up...

```
while (1)
{
    (...)
    while ( _____ || // Check limits to trigger
               _____ || // alarm
               _____ )
    {
        (...)
    }
}
```

- Determine and fill-in suitable X and Y channel boundaries to set off alarm by moving the board and using the debugger to inspect the ADC12 conversion results
- What is the board's total current consumption measured through jumper JP2?

ATC 2008

MSP430 Advanced Technical Conference

33



Lab 2: Timer_B Setup – Solution

```
// Use TBCLK = ACLK, clear TBR, enable TBR
// overflow interrupt
TBCTL = TBSSEL_1 + TBCLR + TBIE;
// Set 1s interval for overflow
TBCCR0 = 32768 - 1;
// Set OUT1 on EQU1, reset on EQU0
TBCCTL1 = OUTMOD_3;
// Set EQU1 event. Used as accelerometer power-on delay and
// ADC12 start of conversion trigger.
TBCCR1 = 655; // For ADXL322
// or
TBCCR1 = 33; // For ADXL330
```

- Note that both flavors of accelerometers have a different settling time

ATC 2008

MSP430 Advanced Technical Conference

34



Lab 2: On-Demand Operation – Solution

```
void System_Init(void)
{
    // Init P6.0 output latch to prepare powering
    // the accelerometer via ACC_PWR
    P6OUT |= 0x01;

#pragma vector = TIMERB1_VECTOR
__interrupt void TIMERB1_ISR(void)
{
    switch (__even_in_range(TBIV, 0x0e))
    {
        case 0x0e:                // TBIFG
            P6DIR |= 0x01;        // Set ACC_PWR to output to
                                // power-up accelerometer
    }
}
```

ATC 2008

MSP430 Advanced Technical Conference

35



Lab 2: Low-Power Mode Handling 1/2 – Solution

```
void main(void)
{
    (...)
    while (1)
    {
        // Wait in low-power mode 3, enable interrupts
        __bis_SR_register(LPM3_bits + GIE);
    }
}
```

- LPM3 is most suitable, since it leaves the 32,768kHz XTAL on while keeping the high-speed DCO and the CPU off

ATC 2008

MSP430 Advanced Technical Conference

36



Lab 2: Low-Power Mode Handling 2/2 – Solution

```
#pragma vector = ADC12_VECTOR
__interrupt void ADC12_ISR(void)
{
    (...)
    // Exit low-power mode
    __bic_SR_register_on_exit(LPM3_bits);
}
```

ATC 2008

MSP430 Advanced Technical Conference

37



Lab 2: Finishing Up... – Solution

```
while (1)
{
    (...)
    while (ADCResultX > 200 || // Check limits to trigger
           ADCResultX < -200 || // alarm
           ADCResultY > 200 ||
           ADCResultY < -200)
    {
        (...)
    }
}
```

- A value of 200 was used since it allows for enough headroom to accommodate non-calibrated systems
- The total current consumption measured through jumper JP2 should be in the 3 μ A range while the system is in LPM3

ATC 2008

MSP430 Advanced Technical Conference

38



Agenda



- Accelerometer Basics
- Interfacing to the MSP430
- Lab: Accelerometer and MSP430 Setup
- Lab: Low-Power Anti-Theft Alarm
- Lab: Tilt Ball

ATC 2008

MSP430 Advanced Technical Conference

39



Lab 3: Goal

- Load and run the provided code on the MSP-EXP430F5438
- Tilting the board to X and Y will move around the ball on the LCD
- Set the board flat on the desk. What happens to the ball?
- Incorporate a calibration mechanism to establish a zero-g position

ATC 2008

MSP430 Advanced Technical Conference

40



Lab 3: Implementing Push-Button Control

```
// Configure P2.x for 'S1' push-button operation

// Configure P2.x as input
P2DIR _____;

// Prepare P2.x pull-up resistor
P2OUT _____;

// Enable P2.x pull-up resistor
P2REN _____;
```

- Check where 'S1' is connected to
- Note that an internal pull-up must be used
- Configure GPIO accordingly
- The button will be checked inside the main while() loop

ATC 2008

MSP430 Advanced Technical Conference

41



Lab 3: Adding Accelerometer Calibration

```
while (1)
{
    // Wait in low-power mode 0, enable interrupts
    __bis_SR_register(LPM0_bits + GIE);

    P1OUT ^= 0x01;           // Toggle LED1

    /* INSERT S1 BUTTON HANDLING HERE */
    /* APPLY CALIBRATION VALUES TO ADCResultX&Y HERE */

    dx = ADCResultX >> 8;    // Scale accelerometer
    dy = ADCResultY >> 8;    // readings
}
```

- Add two variables to the code to hold calibration data
- Use button S1 to capture the ADC12 results at the time of button press and use as zero-g calibration data

ATC 2008

MSP430 Advanced Technical Conference

42



Lab 3: Push-Button Control – Solution

```
// Configure P2.6 for 'S1' push-button operation

// Configure P2.6 as input
P2DIR &= ~0x40;

// Prepare P2.6 pull-up resistor
P2OUT |= 0x40;

// Enable P2.6 pull-up resistor
P2REN |= 0x40;
```

ATC 2008

MSP430 Advanced Technical Conference

43



Lab 3: Accelerometer Calibration – Solution

```
int ADCResultXCal = 0;           // Initialize cal values
int ADCResultYCal = 0;

(...)

while (1)
{
    if (!(P2IN & 0x40))           // Cal button pressed?
    {
        // If yes, store current values
        ADCResultXCal = ADCResultX;
        ADCResultYCal = ADCResultY;
    }

    // Apply calibration values
    ADCResultX -= ADCResultXCal;
    ADCResultY -= ADCResultYCal;
```

ATC 2008

MSP430 Advanced Technical Conference

44



Thank you



ATC 2008
MSP430 Advanced Technical Conference

45

